

V-TOOL Parts List

NO.	Part
①	Case 1 VTL001
②	Case 2 VTL002
③	Release Button VTL003
④	Cutter VTL004
⑤	Push Bar VTL005
⑥	Push Bar Holder VTL006
⑦	Push Bar Guide VTL007
⑧	Stopper 1 VTL008
⑨	Ratchet Lever 1 VTL009
⑩	Shift Bar 1 VTL010
⑪	Shift Bar Spring VTL011
⑫	Inner Guide VTL012
⑬	Case 3 VTL013
⑭	Arm Ass'y VTL014
⑮	Main Spring VTL015
⑯	Holder Roller VTL016
⑰	Trigger VTL017
⑱	Piston Holder VTL018
⑲	Guide Rod VTL019
⑳	Piston VTL020
㉑	Ratchet Pin VTL021
㉒	Stopper 2 VTL022
㉓	Shift Bar 2 VTL023
㉔	Ratchet Lever 2 VTL024
㉕	Fork VTL025
㉖	Tag Holder Attaching Knob VTL026
㉗	Tag keeper VTL027
㉘	Tag Holder TH-M5 VTL028-M5

