



EN
PL
DE
ES
CZ
SK
RO
HU
BG
RU



COUGAR

User Manual

FEATURES


- High-quality sound
- Modern design
- High-quality build
- Line-In volume control

INSTALLATION

- Connect the device to the minijack port and USB

SPECIFICATION

- | | |
|-------------------------------------|----------------|
| • Power Output | 6 W |
| • Speaker diameter | 40 mm |
| • Frequency response | 80 - 20 000 Hz |
| • Impedance | 4 Ω |
| • Cable length between each speaker | 0,9 m |
| • Cable length | 1,5 m |



PACKAGE CONTENT REQUIREMENTS

- | | |
|----------------------------|--|
| • Natec Cougar speakers | • PC or compatible device with a minijack port and USB |
| • Quick installation guide | • Windows® XP/Vista/7/8/10 |

WARRANTY

- 2 years limited manufacturer warranty

SAFETY INFORMATION

- Use as intended.
- Non-authorized repairs or disassembly voids the warranty and may damage the product.
- Dropping or hitting the device may lead to device being damaged, scratched or flawed in other way.
- Do not use the product in low and high temperatures, strong magnetic fields and damp or dusty surroundings.
- Improper usage may break the device.
- Slots and openings in the case are provided for ventilation and should not be obscured. Blocking the vents can cause overheating of the device.

GENERAL

- The safe product, conforming to the EU requirements.
- The product is made in accordance with RoHS European standard.
- The WEEE symbol (the crossed-out wheeled bin) using indicates that this product is not home waste. Appropriate waste management aids in avoiding consequences which are harmful for people and environment and result from dangerous materials used in the device, as well as improper storage and processing. Segregated household waste collection aids recycle materials and components of which the device was made. In order to get detailed information about recycling this product please contact your retailer or a local authority.

