







LCD Monitor Quick Start Guide

Work and Entertainment Monitor | EW Series


DN:EW270Q-EQ-V0

© 2025 BenQ Corporation. All rights reserved. Rights of modification reserved.


Package contents



Power cord



HDMI











USB-C™

*Package contents may vary by region.




P/N: 4J.XXXXX.XXX

Setup




Work and Entertainment Monitor
One-Touch to Switch Between Work and Play

Hotkey




Angle adjustment



Installing Software

Display Pilot 2
efficiently manage your display settings



The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade Dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.